

Mode Flag No.	Function	Value
0	Select 'Manifold Absolute Pressure' mapped calibration	0
	Select 'Throttle Position' mapped calibration	1
	Select for 4 cycle engine	Add 0
	Select for 2 cycle engine (and rotary engine)	Add 4
	Enable 2X Ignition O/P Pulse duration	Add 128
1	1 coil Ignition system	1
	2 coil Ignition system	2
	3 coil Ignition system	3
	4 coil ignition system	4
	Enable "1 coil Ignition system" O/P Inhibit during SYNC loss. ("2,3&4 coil systems" always inhibit during SYNC loss)	Add 8
	Negative triggered Ignition amplifier (module) e.g. Smart HEI	Add 0
	Positive triggered Ignition amplifier (module) e.g. MSD	Add 32
	Cylinder Reference pulse input positive triggered	Add 0
	Cylinder Reference pulse input negative triggered	Add 16
	Cylinder pulse input positive triggered	Add 0
	Cylinder pulse input negative triggered	Add 64
	Cylinder pulse input positive & negative triggered	Add 128
	2	No Air/fuel ratio sensor
Proportional Air/fuel ratio I/P (0.0 - 1.0volt => 10:1 to 30:1 air/fuel ratio)		1
'Bosch' or 'Autronic' 4 wire O ₂ Sensor (for Narrow band 'Emissions control')		2
3	No functions assigned	
4	No functions assigned	
5	Idle Speed Control function (for PWM proportional type valve) to Auxiliary O/P	1
	Boost Control function (for PWM proportional type valve) to Auxiliary O/P	2
	Main Cooling Fan function (Fan 1) to Auxiliary O/P	3
	User Defined PWM O/P Table to Auxiliary O/P	4
	Fuel Used O/P Pulse function to Auxiliary O/P	5
	Redirect User Defined ON/OFF O/P function from Inj 5 to Auxiliary O/P	6
	Select "Throttle Position" as Axis variable for User Defined PWM or ON/OFF O/P	Add 0
Select "Load" as Axis variable for User Defined PWM or ON/OFF O/P	Add 8	
6	PWM O/P frequency = 10Hz	0
	PWM O/P frequency = 20Hz	4
	PWM O/P frequency = 30Hz	8
	PWM O/P frequency = 40Hz	12
7	No functions assigned	
8	Ignition triggering of all Cylinders 1 to 8 allowed	0
	Inhibit cylinder 1 Ignition	Add 1
	Inhibit cylinder 2 Ignition	Add 2
	Inhibit cylinder 3 Ignition	Add 4
	Inhibit cylinder 4 Ignition	Add 8
	Inhibit cylinder 5 ignition	Add 16
	Inhibit cylinder 6 Ignition	Add 32
	Inhibit cylinder 7 Ignition	Add 64
	Inhibit cylinder 8 Ignition	Add 128
9	Ignition triggering of all Cylinders 9 to 16 allowed	0
	Inhibit cylinder 9 Ignition	Add 1
	Inhibit cylinder 10 Ignition	Add 2
	Inhibit cylinder 11 Ignition	Add 4
	Inhibit cylinder 12 Ignition	Add 8
	Inhibit cylinder 13 Ignition	Add 16
	Inhibit cylinder 14 Ignition	Add 32
	Inhibit cylinder 15 Ignition	Add 64
Inhibit cylinder 16 Ignition	Add 128	
10	Use Idle Ignition Timing Table @ Idle	0
	Use Main Ignition Timing Table @ Idle	1
	Ignition Timing Modifier 1 is Charge temperature dependent	Add 0

Mode Flag No.	Function	Value
	Ignition Timing Modifier 1 is Coolant temperature dependent	Add 2
11	Wiring Loom has Power Supply and Fuel Pump / Injector Supply Relays (i.e.: ECU Power Feed is to Pin 25 or 26 from a Relay that de-energizes during Battery Reversal)	0
	Wiring Loom has only Fuel Pump / Injector Supply Relay (i.e.: Direct Power Feed from Ignition Switch / Relay to ECU Pin 29 Only)	1
12	Disable Soft Rev Limit Fuel Cut	0
	Enable Soft Rev Limit Fuel Cut	1
	Disable Soft Rev Limit Spark Cut	Add 0
	Enable Soft Rev Limit Spark Cut	Add 2
13	No functions assigned	
14	No functions assigned	
15	No functions assigned	
Notes		