

Mode Flag No.	Function	Value
0	Select 'Manifold Absolute Pressure' mapped calibration	0
	Select 'Throttle Position' mapped calibration	1
	Select 'Select 'Throttle Position' mapped Fuel calibration with Downstream Manifold Pressure corrected Fuel delivery (Ign calibration is 'Manifold Absolute Pressure' mapped)	8
	Select for 4 cycle engine	Add 0
	Select for 2 cycle engine (and rotary engine)	Add 4
	Enable Open Loop A/F Ratio Table	Add 16
	Enable Open Loop Highway Mode	Add 32
	Enable Closed Loop A/F Ratio Control	Add 64
Enable 2X Ignition O/P Pulse duration	Add 128	
1	1 coil Ignition system	1
	2 coil Ignition system	2
	3 coil Ignition system	3
	4 coil ignition system	4
	Enable "1 coil Ignition system" O/P Inhibit during SYNC loss. ("2,3&4 coil systems" always inhibit during SYNC loss)	Add 8
	Negative triggered Ignition amplifier (module) e.g. Smart HEI	Add 0
	Positive triggered Ignition amplifier (module) e.g. MSD	Add 32
	Cylinder Reference pulse input positive triggered	Add 0
	Cylinder Reference pulse input negative triggered	Add 16
	Cylinder pulse input positive triggered	Add 0
	Cylinder pulse input negative triggered	Add 64
Cylinder pulse input positive & negative triggered	Add 128	
2	No Air/fuel ratio sensor	0
	Proportional Air/fuel ratio I/P (0.0 - 1.0volt => 10:1 to 30:1 air/fuel ratio)	1
	'Bosch' or 'Autronic' 4 wire O ₂ Sensor (for Narrow band 'Emissions control')	2
	Enable Digital I/P Airflow Meter (All PCB revs require an additional external connection. PCB revs prior to 'D' require additional internal circuitry. Consult 'Autronic' for details)	Add 8
Select NTC Air intake Temperature sensor (Requires Internal PCB link U9 pins 1 to 2 (link Jumper JP 7))	Add 16	
3	Enable Auxiliary Cooling Fan (Fan 2) control function to Inj 7 O/P (Only available if Inj 7 not used for Fuel Inj)	0
	Modify Auxiliary Cooling Fan (Fan 2) control function for Charge Cooling	Add 1
4	Set Anti-Lag Extra Fuel Amount	2.6 counts / %
5	Idle Speed Control function (for Bosch 2 wire valve) to Auxiliary O/P	0
	Idle Speed Control function (for PWM proportional type valve) to Auxiliary O/P	1
	Boost Control function (for PWM proportional type valve) to Auxiliary O/P	2
	Main Cooling Fan function (Fan 1) to Auxiliary O/P	3
	User Defined PWM O/P Table or Anti-Lag function to Auxiliary O/P	4
	Fuel Used O/P Pulse function to Auxiliary O/P	5
	Redirect User Defined ON/OFF O/P function from either Inj 5 or Inj 8 to Auxiliary O/P	6
	Select "Throttle Position" as Axis variable for User Defined PWM or Anti-Lag function	Add 0
	Select "Load" as Axis variable for User Defined PWM or Anti-Lag function	Add 8
	Select "Throttle Position" as Axis variable for User Defined ON/OFF O/P	Add 0
	Select "Load" as Axis variable for User Defined ON/OFF O/P	Add 16
Enable ON/OFF O/P function to Auxiliary O/P or Inj 5 O/P or Inj 8 O/P (Auxiliary O/P or Inj 5 O/P if Anti-Lag selected)	Add 32	
Enable Main Cooling Fan (Fan 1) function to Auxiliary O/P or Inj 6 O/P	Add 64	
Enable Anti-Lag function to Auxiliary O/P or Inj 8 O/P	Add 128	
6	PWM O/P frequency = 10Hz	0
	PWM O/P frequency = 20Hz	4
	PWM O/P frequency = 30Hz	8
	PWM O/P frequency = 40Hz	12
	Modify Cylinder Pulse I/P trigger lead to 40° (Standard is 60°)	Add 16
	Inhibit Anti-Lag if "Load" > 100.0	Add 128
7	Select Standard trigger option (Crank pulses per Engine cycle = Cylinder number, Cam pulses per Engine cycle = 1)	0
	Subaru Impreza trigger option (2 x 3 Crank & 3,1,2,1 Cam Pulse Wheels that require a Dual Channel Reluctor Interface)	1
	Mitsubishi Lancer trigger option (4 / rev & 1 x wide, 1 x narrow / rev in Camshaft driven module only)	2
	Select 150° / 90° (V6) trigger option	4
	Modify Cylinder Pulse I/P trigger lead to 75° (Standard is 60°)	Add 8
	Select Anti-Lag Dropped Injection Cool-Down function	Add 16
Select Anti-Lag Throttle Closed Inhibit function	Add 32	

Mode Flag No.	Function	Value
	Select Automatic Anti-Lag Operation (Anti-Lag On for 15 SEC after RPM exceeds 5000)	Add 64
	Select Anti-Lag Control by Switch I/P (Gnd I/P to Activate)	Add 128
8	Ignition triggering of all Cylinders 1 to 8 allowed	0
	Inhibit cylinder 1 Ignition	Add 1
	Inhibit cylinder 2 Ignition	Add 2
	Inhibit cylinder 3 Ignition	Add 4
	Inhibit cylinder 4 Ignition	Add 8
	Inhibit cylinder 5 Ignition	Add 16
	Inhibit cylinder 6 Ignition	Add 32
	Inhibit cylinder 7 Ignition	Add 64
Inhibit cylinder 8 Ignition	Add 128	
9	Ignition triggering of all Cylinders 9 to 16 allowed	0
	Inhibit cylinder 9 Ignition	Add 1
	Inhibit cylinder 10 Ignition	Add 2
	Inhibit cylinder 11 Ignition	Add 4
	Inhibit cylinder 12 Ignition	Add 8
	Inhibit cylinder 13 Ignition	Add 16
	Inhibit cylinder 14 Ignition	Add 32
	Inhibit cylinder 15 Ignition	Add 64
Inhibit cylinder 16 Ignition	Add 128	
10	Use Idle Ignition Timing Table @ Idle	0
	Use Main Ignition Timing Table @ Idle	1
	Ignition Timing Modifier 1 is Charge temperature dependent	Add 0
	Ignition Timing Modifier 1 is Coolant temperature dependent	Add 2
11	Wiring Loom has Power Supply and Fuel Pump / Injector Supply Relays (i.e.: ECU Power Feed is to Pin 25 or 26 from a Relay that de-energizes during Battery Reversal)	0
	Wiring Loom has only Fuel Pump / Injector Supply Relay (i.e.: Direct Power Feed from Ignition Switch / Relay to ECU Pin 29 Only)	1
12	Disable Soft Rev Limit Fuel Cut	0
	Enable Soft Rev Limit Fuel Cut	1
	Disable Soft Rev Limit Spark Cut	Add 0
	Enable Soft Rev Limit Spark Cut	Add 2
13	Disable Extra-Pulse Sync function	0
	Enable Extra-Pulse Sync function (Cam trigger with Cylinder number + 1 pulses per Engine cycle)	128
14	Digital I/P Airflow Meter Trim 1	Typical 30
15	Digital I/P Airflow Meter Trim 2	Typical 120
Notes	User Define PWM table sets Anti-Lag Ignition retard (1% = -1°) A/C Restart Engine Speed = Anti-Lag Cool-down mode minimum RPM A/C Cut Out Engine Speed = Anti-Lag Cool-down mode maximum RPM A/C Restart Delay Time = Anti-Lag Cool-down mode maximum Throttle (20 SEC = 20% TPS) Idle Speed Control Reset Engine Speed = Charge Cooling minimum RPM Fan 2 ON Vehicle Speed Threshold = Charge Cooling maximum 'MAP' Use EBP Limp home Table for Digital I/P Airflow Meter Calibration Idle Speed Control Range = Digital I/P Airflow Meter Trim 3 (Typical 150)	
Warnings	Do not select simultaneous operation of Anti-Lag & Closed Loop A/F Control Functions	